

## 2-Gallon, Polyethylene Safety Can for Liquid Disposal, Red - 14762

### Product Images

---





## Short Description

---

- Superior chemical resistance and leak protection
- Spring-loaded sealed cap automatically vents
- Stainless steel flame arrester
- Design resists accidental tip over

## Description

---

High-density polyethylene (HDPE) disposal cans provide superior chemical resistance and leak protection. Spring-loaded sealed cap, normally closed, automatically vents between 3 and 5 psi (0.2 and 0.35 bar).

Stainless steel handle and hardware with latch-catch system hold the cap in the open position for easy filling and pouring. Large-mouth opening features a built-in stainless steel flame arrester to guard against outside ignition. A current-carrying, patented carbon insert embedded in the container allows for proper grounding. The broad-base design provides stability and resists accidental tip over.

## Specifications

|                            |                            |
|----------------------------|----------------------------|
| Model No                   | 14762                      |
| UPC                        | 697841006003               |
| International Model No.    | 14762Z                     |
| FM Approval                | Yes                        |
| OSHA Compliance            | Yes                        |
| Complies with NFPA Code 30 | Yes                        |
| Color                      | Red                        |
| Material Specifications    | Polyethylene               |
| Dimensions, Exterior       | 14.75" H x 12" Outer Dia.  |
|                            | 375mm H x 305mm Outer Dia. |
| Capacity                   | 2 gallon                   |
| Liter Capacity             | 8                          |
| Fill/Pour Hole inch        | 3.65                       |
| Fill/Pour Hole mm          | 93                         |
| Net Weight, lbs            | 5.4                        |
| Net Weight, kg             | 2.4                        |